

Please be sure to read the enclosed Shark® Owner's Guide prior to using your unit.

Shark ROTATOR®


SPEED
POWERED
LIFT-AWAY™

QUICK START GUIDE

WHAT'S INSIDE

- A** Vacuum Pod
- B** Motorized Floor Nozzle
- C** Handle & Hose
- D** Wand
- E** Crevice Tool
- F** Upholstery Tool

ASSEMBLY



For additional parts and accessories, visit sharkaccessories.com

TIPS



Slide hose clip into back of wand for convenience.




For quick cord access, rotate upper hook down and remove cord.



To store your vacuum, wrap cord around cord hooks.

MAINTENANCE

Empty the dust cup after each use.




TIP: Wash filters every 3 months.

Rinse filters with water only and allow them to air-dry completely. Tap loose dirt from foam filters as needed between washes.

Note: The foam filters may discolor over time. This is normal.

Brushroll access





2 WAYS TO CLEAN

UPRIGHT



Floor Setting

Slide the Floor Selector up or down to choose floor type.



Suction Control


Slide to MIN to increase maneuverability on carpets.
Slide to MAX for more suction on bare floors.



Power



Push the Power button to turn the vacuum on or off.

LIFT-AWAY®



Lift-Away Release

Press release button to lift pod off nozzle.




Handle Release

OR



Wand Release

Attach accessories to handle or wand.



For questions or to register your product, visit us online at sharkclean.com

