

***Shark***<sup>™</sup>

FAN

TF200 Series

OWNER'S GUIDE

---



*Actual unit may vary slightly in appearance and color.*

IMPORTANT SAFETY INSTRUCTIONS

SUITABLE FOR HOUSEHOLD USE ONLY.

WARNING

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY: READ ALL THESE INSTRUCTIONS BEFORE USE.

1.

Do not incinerate battery cells. Consult your local waste authority for information regarding available recycling and/or disposal options.
2.

This appliance comes with a remote control that contains (2) AAA batteries. Dispose of batteries properly. Always keep batteries away from children (choke hazard). Even used batteries can cause injury.
3.

To reduce the risk of an electric shock, connect only to an outlet provided with a Residual Current Device (RCD).
4.

The fan should be used on a stable and level surface.
5.

Never use this fan near pools, bathtubs, showers, basins, or other vessels containing water.
6.

Do not operate any unit with a damaged wire. Discard the unit or return to an authorized service facility for examination and/or repair.
7.

Do not run cord under carpeting. Do not cover charge cord with throw rugs, runners, or similar coverings. Do not route charger cord under furniture or appliances. Keep charger cord away from high-traffic areas. Place charger in an area where the cord will not be tripped over.
8.

If the charger cord is damaged, it should be replaced.
9.

This appliance is not intended for use by anyone (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
10.

Children should be supervised to ensure that they DO NOT play with the appliance.
11.

Cleaning and user maintenance shall not be made by children without supervision.
12.

Prior to cleaning or other maintenance, the appliance must be unplugged from the electrical outlet.
13.

Only use Shark™ branded accessories.
14.

Do not use if appliance is not working as it should, or has been dropped, damaged, left outdoors, or dropped into water.
15.

Turn off all controls before plugging in or unplugging the appliance.
16.

Unplug from electrical outlet when not in use and before any maintenance or cleaning.
17.

Hand wash exterior/hard plastic/non-electronic parts with water only. Do not immerse. Cleaning with chemicals could damage the unit.
18.

Do not attempt to repair or adjust any electrical or mechanical functions of this appliance, as this may cause danger and void the warranty.
19.

Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
20.

Even used batteries may cause severe injury or death.
21.

Call a local poison control center for treatment information.
22.

Compatible battery type is AAA.
23.

The nominal battery voltage is 3V.
24.

Non-rechargeable batteries are not to be recharged.
25.

Do not force discharge, recharge, disassemble, heat above 60°C, or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.
26.

Ensure the batteries are installed correctly according to polarity (+ and -).
27.

Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

28.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
29.

Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

**WARNING: Not suitable for use with solid-state speed controls.**

BATTERY REMOVAL AND DISPOSAL

This remote control uses 2 AAA batteries. When the remote batteries no longer have a charge, they should be removed from the remote and recycled. DO NOT incinerate or compost the product with its integral battery or the remote batteries. When your remote batteries need to be replaced, dispose of them or recycle them in accordance with local ordinances or regulations. In some areas, it is illegal to place spent batteries in the trash or in a municipal solid waste stream. Return spent batteries to an authorized recycling center or to retailer for recycling. Contact your local recycling center for information on where to drop off the spent batteries.

POWER SUPPLY SAFETY

1.

Read and follow all instructions that are on the product or provided with the product.
2.

Do not use an extension cord.
3.

Do not use within 10 feet of pool and do not use in a bathroom.

FCC WARNINGS

**Note:** This equipment has been tested and complies with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. To see if this equipment interferes with radio or television reception, try turning the equipment off and on. To correct any interference:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the receiver.
- Connect the equipment to a different outlet than the receiver.
- Consult the dealer or an experienced technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to two conditions:

1.

This device may not cause harmful interference, and
2.

this device must accept any interference received, including interference that may cause undesired operation.

**Caution:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC statement:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1.

This device may not cause interference.
2.

This device must accept any interference, including interference that may cause undesired operation of the device.

Please be sure to read and save the warnings on other side prior to using your unit.

QUICK START GUIDE

SETTING UP YOUR FAN

Includes:

Base Plate

Base

Remote

Batteries (2x)

Pole and Blade (1x)

Blade (1x)

1

Use assembly stickers to align the **Base** onto the **Base Plate**. Rotate the base clockwise until it clicks into place.

2

Use assembly stickers to align the red arrow printed on the **Pole** with the red arrow printed on the **Base**. Twist the **Pole** clockwise to lock it into the **Base**. Remove tape after assembly has been completed.

3

Remove tape and cardboard from **Pole**. Line up the printed red circle on the **Blade** with the red circle on the inner **Pole**. Press the **Blade** firmly into the **Pole** until it clicks into place.

**Note:** Some models come with the base plate pre-assembled. If your base plate comes pre-assembled, skip to **step 2**.

FEATURES

**PIVOT:** Manually adjust the fan blade left or right to increase horizontal coverage.

**TILT:** Manually rotate the blades to increase horizontal coverage.

**TELESCOPE:** Manually adjust the height of the fan up or down. **(Not all units have telescoping capability.)**

Magnetically store **REMOTE** on back of the fan.

**DUST DEFENSE** panel collects dust to make cleaning easier.

CUSTOMIZABILITY

	<b>Power On</b> <i>Press button on base or remote</i>	Press  to turn the unit on or off.
	<b>Fan Speeds</b> <i>Press and hold button on base or press on remote</i>	Press the  fan icon on the remote or hold down the power button on the unit to switch between fan speeds 1-10. LED lights will indicate selected fan speed.
	<b>Specialty Modes</b> <i>Remote only</i>	<b>Specialty modes vary by model.</b> Press the  Specialty mode icon on the remote to toggle through specialty modes: <b>Sleep Mode:</b> Select Sleep mode to mute chimes, dim lights, and switch to a fan speed optimized for sleep. When Sleep mode is activated, the LED lights will cycle from right to left. <b>BreezeBoost™:</b> Select for a burst of powerful airflow. When BreezeBoost mode is activated, the LED lights will cycle from left to right. <b>NaturalBreeze Mode:</b> In this mode, the fan will create varying airflow patterns to simulate natural wind. When NaturalBreeze mode is activated, one light will flash from left to right.
	<b>Oscillation</b> <i>Remote only</i>	Press the  oscillation icon on the remote to toggle oscillation. LED lights will change when oscillation has been selected. Oscillation settings vary by model. Some models have 3 angles of oscillation, and others have 1. If you'd like to oscillate the unit when it is horizontal, make sure to place it in a location where it will not hit any walls or objects.
	<b>Timer</b> <i>Remote only</i>	<div><div><div><div></div><div>Setting 1: 1 Hour</div></div><div><div></div><div>Setting 2: 2 Hours</div></div><div><div></div><div>Setting 3: 4 Hours</div></div><div><div></div><div>Setting 4: 8 Hours</div></div><div><div></div><div>Setting 5: 12 Hours</div></div></div><div>Press the  timer icon on the remote to switch between timer settings of 1-12 hours. LED lights will indicate how many hours the timer is set for. LEDs will switch off after 20 seconds. To check how long is left on the timer, press the  timer icon and LED lights will appear.</div></div>
	<b>Horizontal Angle Adjust</b> <i>Remote only</i>	Press the  angle adjust arrows on the remote to change the horizontal angle of the fan from a distance.

FOR MORE INFORMATION

**TO DISABLE CHIME:** Hold down the timer and oscillation buttons on the remote at the same time for 3 seconds to disable chiming. Repeat to re-enable.

**CARRYING POSITION:** Carry the unit by the handle on the base while supporting the air duct.



visit [qr.sharkclean.com/TF200series](https://qr.sharkclean.com/TF200series) or  
**SCAN HERE**  
USING YOUR SMARTPHONE CAMERA  
FOR FULL INSTRUCTIONS OR  
TO PURCHASE ACCESSORIES.

READ AND SAVE THESE INSTRUCTIONS

SETTINGS

- The remote uses 2 AAA batteries. For battery installation and replacement instructions, see the Replacing the Batteries in the Remote section.
- If you purchase a replacement remote control, you must pair it with the fan before use. To pair the remote with the fan, hold down the Power button on the fan base for 20 seconds, or until the first and last lights on the display illuminate, then press the Fan Speed Up arrow on the remote.


POWER ON/OFF

To turn the fan on or off, press the **POWER** button on the remote or the **POWER** button on the fan base. The fan will activate in the same speed as in the previous use.

UI Display

All Models

When the fan is powered on, the lights will cycle from left to right, then turn off from right to left.



FAN SPEEDS

UI Display


All Models

Speed 1	○●●●●●	Speed 6	○●●●●●
Speed 2	○●●●●●	Speed 7	○●●●●●
Speed 3	○●●●●●	Speed 8	○●●●●●
Speed 4	○●●●●●	Speed 9	○●●●●●
Speed 5	○●●●●●	Speed 10	○●●●●●

When fan speed is selected, the lights will display the correct speed. For speeds 6-10, all 5 lights will flash before displaying additional lights to show the current speed.

Select one of the 10 speed settings to set the fan airflow level. Press the Fan Speed arrows on the remote or hold down the power button on the base to switch between fan speeds 1-10.

Recommended Speeds	1	2	3	4	5	6	7	8	9	10	Boost
Nursery	✓	✓	✓								
Quiet Sleep	✓	✓	✓	✓							
Working From Home	✓	✓	✓	✓	✓						
Watching TV	✓	✓	✓	✓	✓	✓					
Ambient Noise Sleep		✓	✓	✓	✓	✓	✓	✓			
Cooking				✓	✓	✓	✓	✓	✓	✓	
Exercise					✓	✓	✓	✓	✓	✓	✓
Hot Day Cool Down						✓	✓	✓	✓	✓	✓



OSCILLATION

UI Display

Non-Telescoping Pole Models

Telescoping Pole Models

180 degrees

45 degrees

90 degrees

180 degrees

When oscillation is activated, lights will display to indicate the current angle.

Choose between **OSCILLATION** settings to best suit your needs. Some models have 3 options for angle of oscillation, while other models have one option. To change oscillation settings, press the button to cycle through options on the REMOTE. To turn off oscillation, press the oscillation button until no LEDs are illuminated.

TIMER

UI Display

All Models

1 hour

2 hour

4 hour

8 hour

12 hour

The LED lights will indicate the timer interval for 20 seconds, then turn off.

SPECIALTY MODES

UI Display

All Models

**Sleep Mode:** All lights will flash from right to left.

**BreezeBoost™ Mode:** All lights will flash from left to right.

**NaturalBreeze Mode:** One light will flash from left to right.

Sleep	Fan will mute chimes, dim lights, and switch to a fan speed optimized for sleep. Sleep mode will turn off automatically after 8 hours.
BreezeBoost	Fan will produce a powerful burst of air.
NaturalBreeze	Fan will create varying airflow patterns to simulate natural wind.

HORIZONTAL ANGLE ADJUST

You can use the remote control to change the horizontal angle of the fan from a distance. Press the left or right arrows on the remote to adjust the horizontal angle






MAINTENANCE

- Unplug the fan before doing any cleaning or maintenance.
- We recommend cleaning the fan every 6 months, or as needed.
- We recommend changing the batteries in the remote control every 12 months, or as needed.

DUST DEFENSE




1. Remove the Dust Defense panel from the unit by gently pulling on the finger tab. Note: the mesh filter does not need to be removed from the Dust Defense panel.
2. Use a vacuum cleaner on low speed with a soft brush attachment OR a cloth/towel to remove debris from the Dust Defense panel and the internal mesh screen. **Do NOT use abrasive chemical cleaners.**
3. **OPTIONAL:** If debris is stuck between the mesh filter and the Dust Defense panel, the filter can be removed by gently pulling it out of the tabs on the panel. Rinse the filter and the panel with room-temperature tap water. Allow both the filter and the panel to air-dry for 12 hours before reinstalling. **DO NOT** use the fan when the mesh filter is wet.

DUST DEFENSE (CONTINUED)




4. Replace the Dust Defense panel by inserting the tabs on the bottom of the panel into the indents on the unit and pushing the panel in until it clicks into place.

EXTERNAL CLEANING



To clean the exterior of the fan, wipe it down with a microfiber cloth dampened with warm, soapy water. To prevent damage, do not use abrasive chemical cleaners or too much water.

REPLACING THE BATTERIES IN THE REMOTE



1. To access the batteries, push down gently on the battery door on the back of the remote, then slide the door off. Remove the batteries from the chamber and follow local ordinances for battery disposal.
2. Insert 2 new AAA batteries into the remote. Make sure the batteries are installed in correct orientation as shown in the battery chamber.
3. Slide the battery door back into place on the back of the remote.

TROUBLESHOOTING AND FREQUENTLY ASKED QUESTIONS

GENERAL USE	Why is telescoping not working?	Some models do not have the telescoping capability. See the Quick Start Guide for more information. Models with telescoping have tape on the pole and base to help in the assembly process. Remove the tape after assembly is complete.
	How can I switch from vertical orientation to horizontal orientation?	To pivot the fan vertically or horizontally, grip one end of the fan blade and move it to the desired location. The fan has 360 degrees of rotation.
UI / SETTINGS	Why is oscillation not working?	The fan comes with tape on the pole and the base to help in the assembly process. Remove the tape after assembly is complete. If oscillation is still not working after the tape has been removed, make sure that all assembly touchpoints are correctly assembled. Twist the pole clockwise firmly onto the base until it clicks securely into place to verify that it is installed completely and correctly. If you have an XL model, firmly twist the base counterclockwise onto the base plate until it clicks securely into place to verify that it is installed completely and correctly.
	Where do I put the remote?	Store the remote on the magnetic mount on the top of the pole, on the sticker that shows an outline of the remote.
	Why is my fan changing speeds on its own?	The fan may be in NaturalBreeze mode, which changes automatically to simulate natural wind. To deactivate a Specialty mode, press the Fan Speed icon, or the Specialty mode button in the top right corner of the remote.
	Why is the remote not working?	When using the remote control, make sure it is pointed directly at the LED lights on the front of the fan.  If you purchase a replacement remote control, you must pair it with the fan before use. To pair the remote with the fan, hold down the Power button on the fan base for 20 seconds, or until the first and last lights on the display illuminate, then press the Fan Speed Up arrow on the remote.  If the remote is not working, you may need to change the batteries. See the Replacing the Batteries in the Remote section for instructions.
	Why is the fan unsteady?	Make sure the fan has been assembled correctly and that all parts have been completely clicked into place.  Check the connection points where the base meets the base plate, and where the pole connects to the base.  If the fan is still unsteady, disconnect the parts, then reassemble them, making sure they all click securely into place.
	Why are the lights dim?	The fan may be in Sleep Mode, which dims the lights. To deactivate, press the Specialty mode button in the top right corner of the remote until Sleep Mode is turned off.
	Why did my unit turn off on its own?	Timer mode may be activated. The timer will turn the fan off after 1 to 12 hours. To turn off the timer, press the ⌚ Timer button until all of the indicator lights are turned off.
	How do I disable beeping and chiming?	Press and hold the ⌚ Timer and 🔄 Oscillation buttons at the same time for 3 seconds to disable chiming. Repeat to reactivate chiming sounds.
MAINTENANCE	How do the indicator lights on the base work?	The 5 lights on the base illuminate in different patterns to indicate the status of available fan functions, including power, speed, oscillation angle, timer, and Specialty modes. In all cases, the lights will turn off after 20 seconds.
	How often should I clean the fan and the Dust Defense filter?	We recommend cleaning the fan and the Dust Defense filter every 6 months or as needed.

## TWO (2) YEAR LIMITED WARRANTY

The Two (2) Year Limited Warranty applies to purchases made from authorized retailers of **SharkNinja Operating LLC**. Warranty coverage applies to the original owner and to the original product only and is not transferable.

SharkNinja warrants that the unit shall be free from defects in material and workmanship for a period of two (2) years from the date of purchase when it is used under normal household conditions and maintained according to the requirements outlined in the Owner's Guide, subject to the following conditions and exclusions:

### What is covered by this warranty?

1. The original unit and/or non-wearable parts deemed defective, in SharkNinja's sole discretion, will be repaired or replaced up to two (2) years from the original purchase date.
2. In the event a replacement unit is issued, the warranty coverage ends six (6) months following the receipt date of the replacement unit or the remainder of the existing warranty, whichever is later. SharkNinja reserves the right to replace the unit with one of equal or greater value.

### What is not covered by this warranty?

1. Normal wear and tear of wearable parts (such as batteries, etc.), which require regular maintenance and/or replacement to ensure the proper functioning of your unit, are not covered by this warranty. Replacement parts are available for purchase at [sharkaccessories.com](https://sharkaccessories.com).
2. Any unit that has been tampered with or used for commercial purposes.
3. Damage caused by misuse, abuse, negligent handling, failure to perform required maintenance (e.g., not replacing the filters), or damage due to mishandling in transit.
4. Consequential and incidental damages.

5. Defects caused by repair persons not authorized by SharkNinja. These defects include damages caused in the process of shipping, altering, or repairing the SharkNinja product (or any of its parts) when the repair is performed by a repair person not authorized by SharkNinja.
6. Products purchased, used, or operated outside North America.

### How to get service

If your appliance fails to operate properly while in use under normal household conditions within the warranty period, visit [sharkclean.com/support](https://sharkclean.com/support) for product care and maintenance self-help. Our Customer Service Specialists are also available at **1-855-523-4061** to assist with product support and warranty service options, including the possibility of upgrading to our VIP warranty service options for select product categories. So we may better assist you, please register your product online at [registeryourshark.com](https://registeryourshark.com) and have the product on hand when you call.

SharkNinja will cover the cost for the customer to send in the unit to us for repair or replacement. A fee of \$25.95 (subject to change) will be charged when SharkNinja ships the repaired or replacement unit.

### How to initiate a warranty claim

You must call **1-855-523-4061** to initiate a warranty claim. You will need the receipt as proof of purchase. We also ask that you register your product online at [registeryourshark.com](https://registeryourshark.com) and have the product on hand when you call, so we may better assist you. A Customer Service Specialist will provide you with return and packing instruction information.

### How state law applies

This warranty gives you specific legal rights, and you also may have other rights that vary from state to state. Some states do not permit the exclusion or limitation of incidental or consequential damages, so the above may not apply to you.

## IMPORTANT INFORMATION

### REGISTER YOUR PURCHASE



[registeryourshark.com](https://registeryourshark.com)



Scan QR code using mobile device



### RECORD THIS INFORMATION

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_  
(Keep receipt)

Store of Purchase: \_\_\_\_\_

### TECHNICAL SPECIFICATIONS

Voltage: 120V~ 60Hz / 1.6A  
Watts: 90W

Benefits of registering your product and creating an account:

- Get easier, faster product support and access to warranty information
- Access troubleshooting and product care instructions
- Be among the first to know about exclusive product promotions

**TIP:** You can find the model and serial numbers on the QR code label on the underside of the fan head.

### PLEASE READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

This Owner's Guide is designed to help you get a complete understanding of your new Shark® fan.

SharkNinja Operating LLC  
US: Needham, MA 02494  
CAN: Ville St-Laurent, QC H4S 1A7  
1-800-798-7398  
[sharkclean.com](https://sharkclean.com)

Illustrations may differ from actual product. We are constantly striving to improve our products; therefore the specifications contained herein are subject to change without notice.

This product may be covered by one or more U.S. patents. See [sharkninja.com/patents](https://sharkninja.com/patents) for more information.

### BATTERY REMOVAL AND DISPOSAL

This remote control uses 2 AAA batteries. When the remote batteries no longer have a charge, they should be removed from the remote and recycled. DO NOT incinerate or compost the product with its integral battery or the remote batteries. When your remote batteries need to be replaced, dispose of them or recycle them in accordance with local ordinances or regulations. In some areas, it is illegal to place spent batteries in the trash or in a municipal solid waste stream. Return spent batteries to an authorized recycling center or to retailer for recycling. Contact your local recycling center for information on where to drop off the spent batteries.



### FCC WARNINGS

Note: This unit has been tested and found to comply with FCC limits for Class B digital devices. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To see if this unit interferes with radio or television reception, try turning it off and on.

To correct any interference:

- Reorient or relocate the receiving antenna.
- Increase the distance between the unit and the receiver.
- Connect the unit to a different outlet than the receiver.
- Consult the dealer or an experienced technician for help.

Caution: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate it.